


VERWENDUNG VON VERBINDUNGSTÜCKEN

USE CONNECTORS CORNER SOFA ODIN



Verbinder
und Metallclip
LOS

Connector and
metal clip LOOSE

Verbinder
und Metallclip
FIXIERT

Connector and
metal clip FIXED

VERBINDEN & TRENNEN

Die Metallklammern befinden sich unter dem Longchair des Sofas. Unter dem anderen Teil des Sofas befinden sich die Metallverbindungsstücke.

Wenn Sie die Sofateile voneinander trennen möchten, heben Sie den Sessel mit den Metallklammern an. Sie können die Metallverbindungsstücke, die sich unter dem anderen Element unter dem Sofa befinden, zurückdrehen.

Wenn Sie die Sofateile wieder miteinander verbinden wollen, setzen Sie die Verbindungsstücke gerade vor die Metallklammern und drücken Sie die beiden Sofateile zusammen. Sie werden ein Klickgeräusch hören, die Sofateile ziehen sich zusammen.

CONNECT & DISCONNECT

The metal clips are located under the longchair of the sofa. Under the other part of the sofa are the metal connectors.

If you want to disconnect the sofa parts, lift the longchair with the metal clips. The metal connectors that are under the other element can be turned back under the sofa.

If you want to reconnect the sofa parts, place the connectors right in front of the metal clips and press the two sofa parts against each other. You will hear a click sound, the sofa parts will pull together.

