

UŻYCIE ZŁĄCZY NAROŻNIK ODIN

USE CONNECTORS CORNER SOFA ODIN



Złącze i
metalowy zacisk
LOS

Connector and
metal clip **LOSE**



Złącze i
metalowy zacisk
FIXED

Connector and
metal clip **FIXED**

ŁĄCZENIE I ROZŁĄCZANIE

Metalowe klipsy znajdują się pod podłużnym fotelem sofy. Pod drugą częścią sofy znajdują się metalowe złączka.

Jeśli chcesz rozłączyć części sofy, podnieś podłużne oparcie za pomocą metalowych klipsów. Metalowe łączniki, które znajdują się pod drugim elementem pod sofą, można obrócić z powrotem.


Jeśli chcesz ponownie połączyć części sofy, umieść złączka bezpośrednio przed metalowymi klipsami i dociśnij obie części sofy do siebie. Usłyszysz dźwięk kliknięcia, a części sofy połączą się ze sobą.

CONNECT & DISCONNECT

The metal clips are located under the longchair of the sofa. Under the other part of the sofa are the metal connectors.

If you want to disconnect the sofa parts, lift the longchair with the metal clips. The metal connectors that are under the other element can be turned back under the sofa.

If you want to reconnect the sofa parts, place the connectors right in front of the metal clips and press the two sofa parts against each other. You will hear a click sound, the sofa parts will pull together.



By SIDDE



Złącze



Klips